
List of figures

Figure 1	
Station Administration window	7
Figure 2	
Add Station dialog	13
Figure 3	
Multiple Station Add dialog	14
Figure 4	
Add Template dialog	16
Figure 5	
Station Data dialog	18
Figure 6	
Key Assignments dialog	19
Figure 7	
Directory Numbers dialog	21
Figure 8	
Terminal Numbers dialog	22
Figure 9	
Features dialog	23
Figure 10	
Search by Feature Group dialog (example)	24
Figure 11	
Key Features Edit dialog	25
Figure 12	
Administration dialog	26

Figure 13	
Strip Selection dialog	29
Figure 14	
CPND Administration window	33
Figure 15	
Call Party Name Display dialog	36
Figure 16	
CPND Name dialog	37
Figure 17	
VMC data entry dialog	40
Figure 18	
Record Selection Criteria dialog	46
Figure 19	
Select Data Field dialog	47
Figure 20	
Select System Field dialog	48
Figure 21	
Select Function dialog	48
Figure 22	
Operators dialog	49
Figure 23	
Global Change Specification dialog	52
Figure 24	
Global Change dialog	53
Figure 25	
Synchronization dialog	61
Figure 26	
Station Retrieve All dialog	64
Figure 27	
CPND Name Retrieve dialog	65
Figure 28	
Station Retrieve Since dialog	66

Figure 29	
Station Retrieve Specify dialog	67
Figure 30	
CPND Retrieve dialog	69
Figure 31	
Name Retrieve Specify	70
Figure 32	
Conversion utility window	77
Figure 33	
Report Generation window	84
Figure 34	
Select a Form File dialog	85
Figure 35	
Output Device dialog	87
Figure 36	
Example Report in the Viewer	88
Figure 37	
Export File Name dialog	89
Figure 38	
File Viewer window	92
Figure 39	
Save As dialog	94
Figure 40	
File Summary dialog	94
Figure 41	
Find Text dialog	95
Figure 42	
Printer Selection dialog	96
Figure 43	
Select a Form File dialog	100
Figure 44	
Example blank report form	105

Figure 45	
Select New Section dialog	105
Figure 46	
Edit Section Info dialog	106
Figure 47	
Calculation Field Name dialog	108
Figure 48	
Text Field Parameters	110
Figure 49	
Numeric Field Parameters dialog	111
Figure 50	
Date Field Edit dialog	112
Figure 51	
Report Parameters dialog	113
Figure 52	
Font Selection dialog	115
Figure 53	
Empty Report Form	117
Figure 54	
Select Report view	118
Figure 55	
Inserting Data Field in the Details section	120
Figure 56	
Select Data Field dialog	121
Figure 57	
Naming a Calculation field	121
Figure 58	
Defining a Calculation field	122
Figure 59	
System Field list	123
Figure 60	
Select New Section	123

Figure 61	
Select Data Field	124
Figure 62	
Adding summary information in the Sort Header section	125
Figure 63	
Selecting a printer	126
Figure 64	
Deleting a blank line from the Detail section	127
Figure 65	
Specifying the records to be included in the report	128
Figure 66	
Choosing the example form	129
Figure 67	
Example Report	131
Figure 68	
Select Form dialog	136
Figure 69	
Add station dialog	137
Figure 70	
Add Template dialog	138
Figure 71	
Single station add form	139
Figure 72	
Multiple station add form (default form)	142
Figure 73	
Mode dialog	143
Figure 74	
TN value list	146
Figure 75	
DN value list	147
Figure 76	
CPND parameter fields	149

Figure 77	
VMB fields	150
Figure 78	
FormEdit window for a new form	153
Figure 79	
Select Form dialog	154
Figure 80	
FormEdit window (M2xxx and M3xxx data stations)	155